



Efficiency® Cleaning Instructions

An Efficiency fabric is a lasting and reliable product that combines design, comfort and durability. An Efficiency fabric is very easy to maintain thanks to its excellent care properties. Most common household stains can be easily removed. For an excellent result Efficiency fabrics can be machine-washed at 30° C with no concern about shrinkage or colour loss.

Stain Removal

All common stains are removed from an Efficiency fabric by following the instructions below.

- Treat stains as soon as they occur.
- Remove any excess of soiling material with a blunt knife or, in the case of liquid stains or grease, absorbent paper.
- Prepare a solution of lukewarm water with a neutral detergent.
- Wipe the stain gently with a clean cotton cloth dampened with the solution of soapy water. Avoid strong rubbing.
- With persistent stains it is recommended to damp the upholstery fabric directly with a little bit of soapy water and then rub gently. Repeat the treatment if necessary.
- When the stain has disappeared rub dry with a clean cotton cloth.
- Let dry at room temperature. Do not use the sofa until the cover is completely dry.

Domestic machine washing

All Efficiency fabrics can be machine-washed at 30 ° C. For best results please follow the instructions below.

1. Laundering

- Wash the sofa covers inside out and with the zipper closed.
- When the sofa cover uses Velcro attach a protective cloth or strip over the Velcro to avoid damage to the fabric.
- Use neutral detergents.
- Wash at 30 ° C with a washing program for delicate garments.
- Use minimum centrifugation (as for delicate garments).
- Do not use softener.
- Do not wash with other textiles or garments.
- Do not load the washing machine excessively.

2. Drying

- With the cover still moist stretch in both directions.
- Dry at environmental temperature.
- Avoid direct exposure to sunlight.
- Always assure that the cover is completely dry before usage.

General Care Instructions

Just like any other daily use fabric (garments, curtains, carpets) upholstery fabrics are exposed to dust and other sources of soiling caused by human contact or environmental factors. For this reason, an upholstery fabric needs to be:

- Cleaned regularly by a vacuum cleaner using a furniture nozzle and at low power.
- Wiped off with a clean, humid cloth.



View video *How to remove stains from an Efficiency® upholstery fabric.*